



Pressurized water reactor

A **pressurized water reactor** (**PWR**) is a type of light-water nuclear reactor. PWRs constitute the large majority of the world's nuclear power plants (with notable exceptions being the UK, Japan and Canada). In a PWR, the primary coolant (water) is pumped under high pressure to the reactor core where it is heated by the energy released by the fission of atoms. The heated, high pressure water then flows to a steam generator, where it transfers its thermal energy to lower pressure water of a secondary system where steam is generated. The steam then drives turbines, which spin an electric generator. In contrast to a boiling water reactor (BWR), pressure in the primary coolant loop prevents the water from boiling within the reactor. All light-water reactors use ordinary water as both coolant and neutron moderator. Most use anywhere from two to four vertically mounted steam generators; VVER reactors use horizontal steam generators.

PWRs were originally designed to serve as <u>nuclear</u> <u>marine propulsion</u> for <u>nuclear submarines</u> and were used in the original design of the second commercial power plant at <u>Shippingport Atomic</u> Power Station.



Nuclear Regulatory Commission image of pressurized water reactor vessel heads



PWRs currently operating in the United States are considered <u>Generation II reactors</u>. Russia's <u>VVER</u> reactors are similar to US PWRs, but the <u>VVER-1200</u> is not considered Generation II (see below). France operates many PWRs to generate the bulk of its electricity.

History

Several hundred PWRs are used for marine propulsion in <u>aircraft carriers</u>, nuclear submarines and <u>ice breakers</u>. In the US, they were originally designed at the <u>Oak Ridge National Laboratory</u> for use as a nuclear submarine power plant with a fully operational submarine power plant located at the <u>Idaho National Laboratory</u>. Follow-on work was conducted by Westinghouse <u>Bettis Atomic Power</u> <u>Laboratory</u>.^[1] The first purely commercial nuclear power plant at <u>Shippingport Atomic Power</u> <u>Station</u> was originally designed as a pressurized water reactor (although the first power plant

connected to the grid was at <u>Obninsk</u>, USSR),^[2] on insistence from <u>Admiral Hyman G. Rickover</u> that a viable commercial plant would include none of the "crazy thermodynamic cycles that everyone else wants to build".^[3]

The United States <u>Army Nuclear Power Program</u> operated pressurized water reactors from 1954 to 1974. <u>Three Mile</u> <u>Island Nuclear Generating Station</u> initially operated two pressurized water reactor plants, TMI-1 and TMI-2.^[4] The partial meltdown of TMI-2 in 1979 essentially ended the growth in new construction of nuclear power plants in the United States for two decades.^[5] <u>Watts Bar</u> unit 2 (a Westinghouse 4-loop PWR) came online in 2016, becoming the first new nuclear reactor in the United States since 1996.^[6]




Rancho Seco PWR reactor hall and cooling tower (being decommissioned, 2004)

The pressurized water reactor has several new <u>Generation III reactor</u> evolutionary designs: the <u>AP1000</u>, VVER-1200, ACPR1000+, APR1400, <u>Hualong One</u>, <u>IPWR-900</u> and <u>EPR</u>. The first AP1000 and EPR reactors were connected to the power grid in China in 2018.^[7] In 2020, <u>NuScale</u> <u>Power</u> became the first U.S. company to receive regulatory approval from the Nuclear Regulatory Commission for a <u>small modular reactor^[8]</u> with a modified PWR design.^[9] Also in 2020, the <u>Energy Impact Center</u> introduced the <u>OPEN100</u> project, which published <u>open-source</u> blueprints for the construction of a 100 MW_{electric} nuclear power plant with a PWR design.^[10]

Design

Nuclear fuel in the reactor pressure vessel is engaged in a controlled fission chain reaction, which produces heat, heating the water in the primary coolant loop by thermal conduction through the fuel cladding. [11][12] The hot primary coolant is pumped into a heat exchanger called the steam generator, where it flows through several thousand small tubes.^[13] Heat is transferred through the walls of these tubes to the lower pressure secondary coolant located on the shell side of the exchanger where the secondary coolant




Pictorial explanation of power transfer in a pressurized water reactor. Primary coolant is in orange and the secondary coolant (steam and later feedwater) is in blue.

evaporates to pressurized steam. This transfer of heat is accomplished without mixing the two fluids to prevent the secondary coolant from becoming radioactive.^[11] Some common steam generator arrangements are u-tubes or single pass heat exchangers.

In a nuclear power station, the pressurized steam is fed through a steam turbine which drives an <u>electrical generator</u> connected to the electric grid for transmission. After passing through the turbine the secondary coolant (water-steam mixture) is cooled down and condensed in a <u>condenser</u>. The condenser converts the steam to a liquid so that it can be pumped back into the steam generator, and maintains a vacuum at the turbine outlet so that the pressure drop across the turbine, and hence the energy extracted from the steam, is maximized. Before being fed into the steam generator, the condensed steam (referred to as feedwater) is sometimes preheated in order to minimize thermal shock.^[14]

The steam generated has other uses besides power generation. In nuclear ships and submarines, the steam is fed through a steam turbine connected to a set of speed reduction gears to a shaft used for <u>propulsion</u>. Direct mechanical action by expansion of the steam can be used for a steam-powered <u>aircraft catapult</u> or similar applications. <u>District heating</u> by the



Primary coolant system showing reactor pressure vessel (red), steam generators (purple), Pressurizer (blue), and pumps (green) in the three coolant loop <u>Hualong One</u> design

steam is used in some countries and direct heating is applied to internal plant applications.

Two things are characteristic for the pressurized water reactor (PWR) when compared with other reactor types: coolant loop separation from the steam system and pressure inside the primary coolant loop. In a PWR, there are two separate coolant loops (primary and secondary), which are both filled with demineralized/deionized water. A boiling water reactor, by contrast, has only one coolant loop, while more exotic designs such as breeder reactors use substances other than water for coolant and moderator (e.g. sodium in its liquid state as coolant or graphite as a moderator). The pressure in the primary coolant loop is typically 15–16 megapascals (150–160 bar), which is notably higher than in other <u>nuclear reactors</u>, and nearly twice that of a boiling water reactor (BWR). As an effect of this, only localized boiling occurs and steam will recondense promptly in the bulk fluid. By contrast, in a boiling water reactor the primary coolant is designed to boil.^[15]

Reactor


Coolant

<u>Light water</u> is used as the primary coolant in a PWR. Water enters through the bottom of the reactor's core at about 548 K (275 °C; 527 °F) and is heated as it flows upwards through the reactor core to a temperature of about 588 K (315 °C; 599 °F). The water remains liquid despite the high temperature due to the high pressure in the primary coolant loop, usually around 155 <u>bar</u> (15.5 <u>MPa</u> 153 <u>atm</u>, 2,250 <u>psi</u>). The water in a PWR cannot exceed a temperature of 647 K (374 °C; 705 °F) or a pressure of 22.064 MPa (3200 psi or 218 atm), because those are the <u>critical point</u> of water. [16] Supercritical water reactors are (as of 2022) only a proposed concept in which the

coolant would never leave the <u>supercritical</u> state. However, as this requires even higher pressures than a PWR and can cause issues of corrosion, so far no such reactor has been built.

Pressurizer

Pressure in the primary circuit is maintained by a pressurizer, a separate vessel that is connected to the primary circuit and partially filled with water which is heated to the saturation temperature (boiling point) for the desired pressure by submerged electrical heaters. To achieve a pressure of 155 bars (15.5 MPa), the pressurizer temperature is maintained at 345 °C (653 °F), which gives a subcooling margin (the difference between the pressurizer temperature and the highest temperature in the reactor core) of 30 °C (54 °F). As 345 °C is the boiling point of water at 155 bar, the liquid water is at the edge of a phase change. Thermal transients in the reactor coolant system result in large swings in



pressurizer liquid/steam volume, and total pressurizer volume is designed around absorbing these transients without uncovering the heaters or emptying the pressurizer. Pressure transients in the primary coolant system manifest as temperature transients in the pressurizer and are controlled through the use of automatic heaters and water spray, which raise and lower pressurizer temperature, respectively.^[17]

Pumps

The coolant is pumped around the primary circuit by powerful pumps.^[18] These pumps have a rate of ~100,000 gallons of coolant per minute. After picking up heat as it passes through the reactor core, the primary coolant transfers heat in a steam generator to water in a lower pressure secondary circuit, evaporating the secondary coolant to saturated steam — in most designs 6.2 MPa (60 atm, 900 <u>psia</u>), 275 °C (530 °F) — for use in the steam turbine. The cooled primary coolant is then returned to the reactor vessel to be heated again.

Moderator

Pressurized water reactors, like all <u>thermal reactor</u> designs, require the fast fission neutrons to be slowed (a process called moderation or thermalizing) in order to interact with the nuclear fuel and sustain the chain reaction. In PWRs the coolant water is used as a <u>moderator</u> by letting the neutrons undergo multiple collisions with light hydrogen atoms in the water, losing speed in the

process. This "moderating" of neutrons will happen more often when the water is more dense (more collisions will occur). The use of water as a moderator is an important safety feature of PWRs, as an increase in temperature may cause the water to expand, giving greater 'gaps' between the water molecules and reducing the probability of thermalization — thereby reducing the extent to which neutrons are slowed and hence reducing the reactivity in the reactor. Therefore, if reactivity increases beyond normal, the reduced moderation of neutrons will cause the chain reaction to slow down, producing less heat. This property, known as the negative temperature coefficient of reactivity, makes PWR reactors very stable. This process is referred to as 'Self-Regulating', i.e. the hotter the coolant becomes, the less reactive the plant becomes, shutting itself down slightly to compensate and vice versa. Thus the plant controls itself around a given temperature set by the position of the control rods.

In contrast, the Soviet RBMK reactor design used at Chernobyl, which uses graphite instead of water as the moderator and uses boiling water as the coolant, has a large positive thermal coefficient of reactivity. This means reactivity and heat generation increases when coolant and fuel temperatures increase, which makes the RBMK design less stable than pressurized water reactors at high operating temperature. In addition to its property of slowing down neutrons when serving as a moderator, water also has a property of absorbing neutrons, albeit to a lesser degree. When the coolant water temperature increases, the boiling increases, which creates voids. Thus there is less water to absorb thermal neutrons that have already been slowed by the graphite moderator, causing an increase in reactivity. This property is called the void coefficient of reactivity, and in an RBMK reactor like Chernobyl, the void coefficient is positive, and fairly large, making it very hard to regulate when the reaction begins to run away. The RBMK reactors also have a flawed control rods design in which during rapid scrams, the graphite reaction enhancement tips of the rods would displace water at the bottom of the reactor and locally increase reactivity there. This is called the "positive scram effect" that is unique to the flawed RBMK control rods design. These design flaws, in addition to operator errors that pushed the reactor to its limits, are generally seen as the causes of the Chernobyl disaster.^[19]

The Canadian <u>CANDU</u> heavy water reactor design have a slight positive void coefficient, these reactors mitigate this issues with a number of built-in advanced passive safety systems not found in the Soviet RBMK design. No criticality could occur in a CANDU reactor or any other heavy water reactor when ordinary light water is supplied to the reactor as an emergency coolant. Depending on <u>burnup</u>, <u>boric acid</u> or another <u>neutron poison</u> will have to be added to emergency coolant to avoid a criticality accident.

PWRs are designed to be maintained in an undermoderated state, meaning that there is room for increased water volume or density to further increase moderation, because if moderation were near saturation, then a reduction in density of the moderator/coolant could reduce neutron absorption significantly while reducing moderation only slightly, making the void coefficient positive. Also, light water is actually a somewhat stronger moderator of neutrons than heavy water, though heavy water's neutron absorption is much lower. Because of these two facts, light water reactors have a relatively small moderator volume and therefore have compact cores. One next generation design, the <u>supercritical water reactor</u>, is even less moderated. A less moderated neutron energy spectrum does worsen the capture/fission ratio for ²³⁵U and especially ²³⁹Pu, meaning that more fissile

nuclei fail to fission on neutron absorption and instead capture the neutron to become a heavier nonfissile isotope, wasting one or more neutrons and increasing accumulation of heavy transuranic actinides, some of which have long half-lives.

Fuel

After enrichment, the <u>uranium dioxide</u> (UO_2) powder is fired in a high-temperature, <u>sintering</u> furnace to create hard, ceramic pellets of enriched uranium dioxide. The cylindrical pellets are then clad in a corrosion-resistant zirconium metal alloy <u>Zircaloy</u> which are backfilled with helium to aid heat conduction and detect leakages. <u>Zircaloy</u> is chosen because of its mechanical properties and its low absorption cross section.^[20] The finished fuel rods are grouped in fuel assemblies, called fuel bundles, that are then used to build the core of the reactor. A typical PWR has fuel assemblies of 200 to



PWR fuel bundle This fuel bundle is from a pressurized water reactor of the nuclear passenger and cargo ship <u>NS Savannah</u>. Designed and built by Babcock & Wilcox.

300 rods each, and a large reactor would have about 150–250 such assemblies with 80–100 tons of uranium in all. Generally, the fuel bundles consist of fuel rods bundled 14 × 14 to 17 × 17. A PWR produces on the order of 900 to 1,600 MW_e. PWR fuel bundles are about 4 meters in length.^[21]

Refuelings for most commercial PWRs is on an 18–24 month cycle. Approximately one third of the core is replaced each refueling, though some more modern refueling schemes may reduce refuel time to a few days and allow refueling to occur on a shorter periodicity.^[22]

Control

In PWRs reactor power can be viewed as following steam (turbine) demand due to the reactivity feedback of the temperature change caused by increased or decreased steam flow. (See: <u>Negative</u> temperature coefficient.) Boron and cadmium control rods are used to maintain primary system temperature at the desired point. In order to decrease power, the operator throttles shut turbine inlet valves. This would result in less steam being drawn from the steam generators. This results in the primary loop increasing in temperature. The higher temperature causes the density of the primary reactor coolant water to decrease, allowing higher neutron speeds, thus less fission and decreased power output. This decrease of power will eventually result in primary system temperature returning to its previous steady-state value. The operator can control the steady state operating temperature by addition of boric acid and/or movement of control rods.

Reactivity adjustment to maintain 100% power as the fuel is burned up in most commercial PWRs is normally achieved by varying the concentration of boric acid dissolved in the primary reactor coolant. Boron readily absorbs neutrons and increasing or decreasing its concentration in the reactor coolant will therefore affect the neutron activity correspondingly. An entire control system involving high pressure pumps (usually called the charging and letdown system) is required to remove water from the high pressure primary loop and re-inject the water back in with differing concentrations of boric acid. The reactor control rods, inserted through the reactor vessel head directly into the fuel bundles, are moved for the following reasons: to start up the reactor, to shut

down the primary nuclear reactions in the reactor, to accommodate short term transients, such as changes to load on the turbine,

The control rods can also be used to compensate for <u>nuclear poison</u> inventory and to compensate for <u>nuclear fuel</u> depletion. However, these effects are more usually accommodated by altering the primary coolant boric acid concentration.

In contrast, <u>BWRs</u> have no boron in the reactor coolant and control the reactor power by adjusting the reactor coolant flow rate.

Advantages

PWR reactors are very stable due to their tendency to produce less power as temperatures increase; this makes the reactor easier to operate from a stability standpoint.

PWR turbine cycle loop is separate from the primary loop, so the water in the secondary loop is not contaminated by radioactive materials.

PWRs can passively scram the reactor in case offsite power is lost to immediately stop the primary nuclear reaction. The control rods are held by electromagnets and fall by gravity when current is lost; full insertion safely shuts down the primary nuclear reaction.

PWR technology is favoured by nations seeking to develop a nuclear navy; the compact reactors fit well in nuclear submarines and other nuclear ships.

PWRs are the most deployed type of reactor globally, allowing for a wide range of suppliers of new plants and parts for existing plants. Due to long experience with their operation they are the closest thing to mature technology that exists in nuclear energy.

PWRs - depending on type - can be fueled with <u>MOX-fuel</u> and/or the Russian <u>Remix Fuel</u> (which has a lower ²³⁹Pu and a higher ²³⁵U content than "regular" U/Pu MOX-fuel) allowing for a (partially) closed nuclear fuel cycle.

Water is a nontoxic, transparent, chemically unreactive (by comparison with e.g. <u>NaK</u>) coolant that is liquid at room temperature which makes visual inspection and maintenance easier. It is also easy and cheap to obtain unlike heavy water or even nuclear graphite.

Compared to reactors operating on <u>natural uranium</u>, PWRs can achieve a relatively high <u>burnup</u>. A typical PWR will exchange a quarter to a third of its fuel load every 18-24 months and have maintenance and inspection, that requires the reactor to be shut down, scheduled for this window. While more <u>uranium ore</u> is consumed per unit of electricity produced than in a natural uranium fueled reactor, the amount of <u>spent fuel</u> is less with the balance being <u>depleted uranium</u> whose radiological danger is lower than that of natural uranium.

Disadvantages

The coolant water must be highly pressurized to remain liquid at high temperatures. This requires high strength piping and a heavy pressure vessel and hence increases construction costs. The higher pressure can increase the consequences of a <u>loss-of-coolant accident</u>.^[23] The <u>reactor</u> <u>pressure vessel</u> is manufactured from ductile steel but, as the plant is operated, neutron flux from the reactor causes this steel to become less ductile. Eventually the <u>ductility</u> of the steel will reach limits determined by the applicable boiler and pressure vessel standards, and the pressure vessel must be repaired or replaced. This might not be practical or economic, and so determines the life of the plant.

Additional high pressure components such as reactor coolant pumps, pressurizer, and steam generators are also needed. This also increases the capital cost and complexity of a PWR power plant.

The high temperature water coolant with <u>boric acid</u> dissolved in it is corrosive to <u>carbon steel</u> (but not <u>stainless steel</u>); this can cause radioactive corrosion products to circulate in the primary coolant loop. This not only limits the lifetime of the reactor, but the systems that filter out the corrosion products and adjust the boric acid concentration add significantly to the overall cost of the reactor and to radiation exposure. In one instance, this has resulted in severe corrosion to control rod drive mechanisms when the boric acid solution leaked through the seal between the mechanism itself and the primary system.^{[24][25]}

Due to the requirement to load a pressurized water reactor's primary coolant loop with boron, undesirable radioactive secondary tritium production in the water is over 25 times greater than in boiling water reactors of similar power, owing to the latter's absence of the neutron moderating element in its coolant loop. The tritium is created by the absorption of a fast neutron in the nucleus of a boron-10 atom which subsequently splits into a lithium-7 and tritium atom. Pressurized water reactors annually emit several hundred <u>curies</u> of tritium to the environment as part of normal operation. [26]

Natural uranium is only 0.7% uranium-235, the isotope necessary for thermal reactors. This makes it necessary to enrich the uranium fuel, which significantly increases the costs of fuel production. Compared to reactors operating on natural uranium, less energy is generated per unit of uranium ore even though a higher burnup can be achieved. <u>Nuclear reprocessing</u> can "stretch" the fuel supply of both natural uranium and enriched uranium reactors but is virtually only practiced for light water reactors operating with lightly enriched fuel as spent fuel from e.g. CANDU reactors is very low in fissile material.

Because water acts as a neutron moderator, it is not possible to build a <u>fast-neutron reactor</u> with a PWR design. A <u>reduced moderation water reactor</u> may however achieve a <u>breeding ratio</u> greater than unity, though this reactor design has disadvantages of its own.^[27]

<u>Spent fuel</u> from a PWR usually has a higher content of <u>fissile material</u> than natural uranium. Without <u>nuclear reprocessing</u>, this fissile material cannot be used as fuel in a PWR. It can, however, be used in a <u>CANDU</u> with only minimal reprocessing in a process called "DUPIC" - Direct Use of spent PWR fuel in CANDU.^[28]

Thermal efficiency, while better than for boiling water reactors, cannot achieve the values of reactors with higher operating temperatures such as those cooled with high temperature gases, liquid metals or molten salts. Similarly process heat drawn from a PWR is not suitable for most industrial applications as those require temperatures in excess of 400 °C (752 °F).


<u>Radiolysis</u> and certain accident scenarios which involve interactions between hot steam and zircalloy cladding can produce hydrogen from the cooling water leading to <u>hydrogen explosions</u> as a potential accident scenario. During the <u>Fukushima nuclear accident</u> a hydrogen explosion damaging the containment building was a major concern, though the reactors at the plant were <u>BWRs</u>, which owing to the steam at the top of the pressure vessel by design carry a greater risk of this happening. Some reactors contain catalytic recombiners which let the hydrogen react with ambient oxygen in a non-explosive fashion.

See also

- Boiling water reactor
- List of PWR reactors
- Nuclear safety systems
- KEPCO Advanced Power Reactor 1400 (APR-1400)
- Rosatom VVER-1200 (or AES-2006)
- Areva EPR
- Westinghouse Advanced Passive 1000 (AP1000)
- Chinese Hualong One (or HPR1000)
- Indian IPWR-900

Notes

- 1. "Rickover: Setting the Nuclear Navy's Course" (https://web.archive.org/web/20071021213713/h ttp://www.ornl.net/info/ornlreview/rev25-34/chapter3sb8.htm). *ORNL Review*. Oak Ridge National Laboratory, U.S. Dept. of Energy. Archived from the original (http://www.ornl.net/info/or nlreview/rev25-34/chapter3sb8.htm) on 2007-10-21. Retrieved 2008-05-21.
- "Russia's Nuclear Fuel Cycle" (http://world-nuclear.org/information-library/country-profiles/count ries-o-s/russia-nuclear-fuel-cycle.aspx). world-nuclear.org. World Nuclear Association. May 2018. Retrieved 2018-09-17. "In 1954 the world's first nuclear powered electricity generator began operation in the then closed city of Obninsk at the Institute of Physics and Power Engineering (FEI or IPPE)."
- 3. Rockwell, Theodore (1992). *The Rickover Effect.* Naval Institute Press. p. 162. ISBN 978-1557507020.
- 4. Mosey 1990, pp. 69-71



- 5. "50 Years of Nuclear Energy" (http://www.iaea.org/About/Policy/GC/GC48/Documents/gc48inf-4_ftn3.pdf) (PDF). IAEA. Retrieved 2008-12-29.
- 6. Blau, Max (October 21, 2016). "First new US nuclear reactor in 20 years goes live" (https://ww w.cnn.com/2016/10/20/us/tennessee-nuclear-power-plant/index.html). CNN. Retrieved November 23, 2021.
- 7. Proctor, Darrell (July 5, 2018). "First Commercial AP1000, EPR Reactors Connected to Grid" (h ttps://www.powermag.com/first-commercial-ap1000-epr-reactors-connected-to-grid/). *Power Magazine*. Retrieved November 23, 2021.
- 8. Ridler, Keith (September 2, 2020). "US gives first-ever OK for small commercial nuclear reactor" (https://apnews.com/article/technology-or-state-wire-ut-state-wire-id-state-wire-science -910766c07afd96fbe2bd875e16087464). Associated Press. Retrieved November 23, 2021.
- 9. Price, Mike (August 22, 2019). "A look at the NuScale small modular nuclear reactor project" (h ttps://www.eastidahonews.com/2019/08/a-comprehensive-look-at-the-nuscale-small-modular-r eactor-project/). *East Idaho News*. Retrieved November 23, 2021.
- 10. Takahashi, Dean (February 25, 2020). "Last Energy raises \$3 million to fight climate change with nuclear energy" (https://venturebeat.com/2020/02/25/last-energy-raises-3-million-to-fight-cl imate-change-with-nuclear-energy/). *VentureBeat*. Retrieved November 23, 2021.
- 11. "NUCLEAR 101: How Does a Nuclear Reactor Work?" (https://www.energy.gov/ne/articles/nuclear-101-how-does-nuclear-reactor-work). *Energy.gov*. Retrieved 20 December 2022.
- 12. Jacquemain 2015, pp. 12, 21
- 13. <u>Riznic 2017</u>, p. 3
- 14. Glasstone & Sesonske 1994, p. 769
- 15. Duderstadt & Hamilton 1976, pp. 91-92
- 16. International Association for the Properties of Water and Steam, 2007.
- 17. Glasstone & Sesonske 1994, p. 767
- 18. Tong 1988, p. 175
- 19. Mosey 1990, pp. 92-94
- Forty, C.B.A.; P.J. Karditsas. "Uses of Zirconium Alloys in Fusion Applications" (https://web.arc hive.org/web/20090225155448/http://www.fusion.org.uk/techdocs/icfrm9_fortkard.pdf) (PDF). EURATOM/UKAEA Fusion Association, Culham Science Center. Archived from the original (htt p://www.fusion.org.uk/techdocs/icfrm9_fortkard.pdf) (PDF) on February 25, 2009. Retrieved 2008-05-21.
- 21. Glasstone & Sesonske 1994, p. 21
- 22. Duderstadt & Hamilton 1976, p. 598
- 23. Tong 1988, pp. 216-217
- 24. "Davis-Besse: The Reactor with a Hole in its Head" (https://web.archive.org/web/20081027134 541/http://www.ucsusa.org/assets/documents/nuclear_power/acfnx8tzc.pdf) (PDF). UCS --Aging Nuclear Plants. Union of Concerned Scientists. Archived from the original (http://www.uc susa.org/assets/documents/nuclear_power/acfnx8tzc.pdf) (PDF) on 2008-10-27. Retrieved 2008-07-01.
- 25. Wald, Matthew (May 1, 2003). "Extraordinary Reactor Leak Gets the Industry's Attention" (http s://www.nytimes.com/2003/05/01/us/extraordinary-reactor-leak-gets-the-industry-s-attention.ht ml). <u>New York Times</u>. Retrieved 2009-09-10.
- 26. "Frequently Asked Questions About Liquid Radioactive Releases" (https://www.nrc.gov/reactor s/operating/ops-experience/tritium/faqs.html).
- 27. Duderstadt & Hamilton 1976, p. 86

28. Wang, Brian (2009-04-15). "DUPIC Fuel Cycle : Direct Use of Pressurized Water Reactor Spent Fuel in CANDU" (https://www.nextbigfuture.com/2009/04/dupic-fuel-cycle-direct-use-of.h tml). NextBigFuture.com. Retrieved 2022-03-08.

References

- Duderstadt, James J.; Hamilton, Louis J. (1976). Nuclear Reactor Analysis. Wiley. ISBN 978-0471223634.
- Glasstone, Samuel; Sesonske, Alexander (1994). Nuclear Reactor Engineering. Chapman and Hall. ISBN 978-0412985218.
- Jacquemain, Didier (2015). Nuclear Power Reactor Core Melt Accidents (https://www.edp-ope n.org/images/stories/books/fulldl/Nuclear_Power_Reactor_Core_Melt_Accidents.pdf) (PDF).
 Institut de radioprotection et de sûreté nucléaire. p. 12. ISBN 978-2-7598-1835-8.
- Mosey, David (1990). *Reactor Accidents*. Nuclear Engineering International Special Publications. pp. 92–94. ISBN 978-0408061988.
- Riznic, Jovica (2017). Steam Generators for Nuclear Power Plants (https://doi.org/10.1016/B97 8-0-08-100894-2.00001-7). Woodhead Publishing. doi:10.1016/B978-0-08-100894-2.00001-7 (https://doi.org/10.1016%2FB978-0-08-100894-2.00001-7). ISBN 9780081008942.
- Tong, L.S. (1988). *Principles of Design Improvement for Light Water Reactors*. Hemisphere. ISBN 978-0891164166.

External links

- Nuclear Science and Engineering (http://ocw.mit.edu/courses/nuclear-engineering/) at MIT OpenCourseWare.
- Document archives (https://www.nrc.gov/reading-rm/doc-collections/) at the website of the United States Nuclear Regulatory Commission.
- Operating Principles of a Pressurized Water Reactor (https://www.youtube.com/watch?v=MSFg mLW1Crw) (YouTube video).
- Fuel Consumption of a Pressurized Water Reactor (http://www.nuclear-power.net/nucl

Retrieved from "https://en.wikipedia.org/w/index.php?title=Pressurized_water_reactor&oldid=1228548310"